

# UNWINDER / WINDER OF FENCING WIRE

**WINDS AND UNWINDS ALL FENCING WIRES (PLAIN, BARBED WIRE...). IDEAL WHEN DISMOUNTING YOUR FENCES.**



**Winds and unwinds all kinds of fencing wires**

**2 models: 1 or 2 coils, with or without removable flange**

Coils are adaptable on: CLOTURMATIC RXB.

**Maximum capacity: 15 km** in Ø 2 mm with plain wire; for barbed wire, it depends on the picks

**Independant tightening adjustment** of the wire

**Hydraulic wire guide** controlled by the operator

**Quick and simple lading and changing of the coil; no key or tool needed**

- 1 - Lower the machine so the coil is on the ground
- 2 - Pull the handle for unlocking the hydraulic motor and the coil is released

## TECHNICAL CHARACTERISTICS

	1 coil	2 coils
Models		
Linkage	Front or rear 3 point linkage number 1 and 2	Front or rear 3 point linkage number 1 and 2
Drive	Tractor pump with 4 couplers 1/2	Tractor pump with 4 couplers 1/2
Dimensions (L x W x H)	1000 x 1710 x 960 mm	1000 x 1740 x 980 mm
Weight	190 Kg	230 Kg

Oil flow	20 L/min	20 L/min
(min. / max.)	50 L/min	50 L/min
Working speed	10 Km/h max.	10 Km/h max.



